

## IX Series

### Avigilon™ ACC7® Integration

**Platform and Version:** Avigilon ACC7 | **Tested Stations:** IX-DA, IX-DVM, IX-DV, IX-DVF-\* | **Compatible Firmware:** Version 6.0 or newer

#### Getting Started

This application note shows the required configuration to add compatible IX Series stations to Avigilon™ ACC7. These steps are meant to be followed after the general configuration of the IX Series stations has been completed. Please refer to the IX Series Quick Start Guide for more information.

#### Support Tool - Configuring ONVIF® and RTSP Credentials

On the left-hand side menu, expand **Station Information** and select **ID and Password**. This screen will allow the addition of an ONVIF/RTSP ID and ONVIF/RTSP Password. Both credentials are required for integration with the ACC7 client. Special characters may be used when creating an ID and Password with Support Tool Version 8.30 or above.

**Table View**

---

**Station View**

- Station Information
- Identification
- ID and Password**
- Time
- Expanded System

Row Previous Next

Enter Number  Display

Number of Notes: 3

1. Unique password recommended for each station.
2. Set a strong password that is difficult to guess.

Station Information				Station Information				ID and Password				
Identification				ID and Password								
#	Number	Name	Location	Station Type	Administrator ID	Administrator Password	User ID	User Password	ONVIF ID	ONVIF Password	RTSP ID	RTSP Password
0001	0001	Master Station		IX-MV7-*	admin123	*****						
0002	0002	Video Station		IX-DV, IX-DVF(-*)	admin123	*****			aiphone	*****	aiphone	*****

**ONVIF ID and Password**

Enter an ID and Password.

**RTSP ID and Password**

Enter the same ID and Password used for the ONVIF ID and Password.

Click **Update** to save the changes.

#### Support Tool - Setting File Upload

From the top menu bar, click **File(F)** and select **Upload Settings to Station**.

Station List

Select	Number	Name	Location	Station Type	Status
<input checked="" type="checkbox"/>	0001	Master Station		IX-MV7-*	-
<input checked="" type="checkbox"/>	0002	Video Station		IX-DV, IX-DVF(-*)	-

Select Station by Type:

All Select Unselect

**Select Stations**

Use the drop-down menu under Select Station by Type and choose **All**, then click **Select**.

**Settings**

Click **Settings** to upload the configuration settings to each station.



Select file type to be uploaded

Settings Sounds Schedule

For more details about the features and information above, please contact Technical Support.

## WEB GUI - Configuring ONVIF® and RTSP Credentials

Open a web browser and navigate to the IX Series door station using <https://ipaddress/webset.cgi?login> and login with the ID and Password. This method is used for scenarios where the door station count is low. Aiphone does not recommend this method for systems with more than two door stations or systems initially programmed using the IX Support Tool.



### Station Information

Select ID and Password from the menu on the left.


### ID and Password

Enter an ONVIF and RTSP ID and Password.

Click **Update** to save the changes.

## ONVIF® Registration

Open the client software to register the IX Series stations and follow the steps below for ONVIF® registration.



### Connecting Devices

Login to the ACC7 server and proceed to the site setup. Click **Connect/Disconnect Devices**.

### Connecting the Door Station

Select the door station to be added to the ACC7 server and click **Connect**.


### ID and Password

The ACC7 server will attempt to connect and prompt for an ID and Password. Enter the **ONVIF® ID** and **Password** created in Support Tool.

For more details about the features and information above, please contact Technical Support.

## RTSP Registration

If the video door station is not showing up in the Discovered Devices list, the camera may be in a different broadcast domain. In this case RTSP can be used to connect the camera by selecting **Find Device** but, ONVIF® functions will be lost.



### Connecting the Door Station

Select **Find Device** and set the device type to **Generic RTSP**.

Stream URL:  
rtsp://username:password@ip address/udp/unicast/aiphone\_H264  
rtsp://username:password@ip address/udp/unicast/aiphone\_JPEG